

## **PIR MP .ALERT**

### **Function introduction :**

- A, When the body is near, it will automatically start the alarm;
- B, The highest sensitivity in the range of 4-5 meters;
- C, Put the alarm cat or paste in a certain height, away from the body within 5 meters within the angular range  $120^{\circ}$  left and right, as long as people or animals, swaying back and forth in a very short time, induction start.
- D. Connectivity can listen to a location within 10 meters of the situation, the sound is very clear.

### **using methods:**

- A) turning on: open the deck lid, insert the SIM card follow the instructions in Figure deck automatically boot.
- B) number binding: after 15 seconds calling from mobile phone and other communication tools, It will connect automatically. When you hear voice call, the binding succeeds. This operation is very simple.

- C) while human body moving back and forth passing the sensor, the product will call the binding number.

**Remote-control setting:**

- 1) Send "0000" to the SIM card number after a successful turn off this feature;
- 2) Send "1111" is open induction.

**Operating frequency:**

850MHZ, 900MHZ, 1800MHZ, 1900MHZ;

**Standby time:**

For body sensing:5-7days not for body sensing:10 days.

**product specification:**

A, product size: 4.50\*3.0\*1.40 cm

B, working current: below 10 mA

C. **idle current : below 0.05 mA**

C, sensitivity: 5-8m center angle 90°